


Thank you for using our tripod for photography, Before using the product, please read the instruction carefully.




# Tripod User Manual

Model#: PO-254X1A

CAVIX®

List including:



Tripod\*1




User manual\*1




Allen Key\*1




Spike\*3




The parts can be separately to use, like the tripod or head.



disassemble the leg with sponge cover , and connect with center column separately to transformed to monopod




The center column can be adjustable the length by adjustable knob.



Mount the camera on quick release plate

Release+lock the quick release clamp


Adjustable the rotating ball for intended shooting angle.







Bubble level

Control the base(release+lock)


Before using the equipment to shooting, do please check all knobs were adjustable well or not. Fix the quick release plate, release the ball head+pedestal lock and adjust the intended shooting angle for shooting. Do please hold your camera while releasing the lock, in case the camera flip over and damaged.




Press the angle adjuster to adjust the angle of the leg, there are three steps of leg angle adjustable, e.g. 80 degree, 55 degree, 22 degree




Rotate the leg adjuster to adjust the leg's length, and push back leg and rotate the knob to retract the leg.



Removeable the hook on center column



Get out the center column



Center column inverted