




# TRIPOD USER'S MANUAL

Model#:W-222D0C Kit




中山精格电子科技有限公司  
ZHONGSHAN JINGGE ELECTRONIC TECHNOLOGY CO., LTD.

## HEAD




The ball-head + Pedestal lock to control the ball's locking

## LEG ANGLE




Out pull the adjuster to adjust the leg's angle, there are three stops of leg angle adjustable, e.g. 85 degree, 55 degree, 25 degree. And press the button to lock after angle was adjusted well.


## TRIPOD LEG EXTEND



## HEAD INSTALLING



## FOOT SPIKE INSTALLING



## NOTICE

1. Do not exceed the large capacity of loading.
2. Make sure to lock and keep safe when operating the tripod.
3. The best working temperature is between Minus 40 degree - 100 degree, do please use it in the temperature range. Do not use the tripod at sea.
4. Do not keep the product under the sunshine for long time.
5. To make sure all equipments (like camera) was taken down from the tripod when on transportation.
6. After working, do keep it clean of all accessories and tripod before packing.
7. Do please use the standard lube (oil) if need.
8. Do not connect any power when using.



### Friendly Tips

If you need moving the tripod position on shooting, do please take down the camera (especially for the telephoto lens), it may broke down your camera.