



TRIPOD USER'S MANUAL

Model#:W-284D2C Kit




中山精格电子科技有限公司
ZHONGSHAN JINGGE ELECTRONIC TECHNOLOGY CO., LTD.

HEAD




LEG ANGLE




Tripod's angle adjust:
Out pull the adjuster to adjust the leg's angle, there are three stops of leg angle adjustable, e.g.85 degree,55 degree, 23 degree. And press the button to lock after angle was adjusted well.


TRIPOD LEG EXTEND



HEAD INSTALLING



FOOT SPIKE INSTALLING



Can use the allen key(3.5mm)to assist to fix foot spike tightly
Friendly reminder: the foot spike here was dual use(one side is short and the other is long)

NOTICE

1. Do not exceed the large capacity of loading.
2. Make sure to lock and keep safe when operating the tripod.
3. The best working temperature is between Minus 40 degree - 100 degree, do please use it in the temperature range. Do not use the tripod at sea.
4. Do not keep the product under the sunshine for long time.
5. To make sure all equipments(like camera)was taken down from the tripod when on transportation.
6. After working, do keep it clean of all accessories and tripod before packing.
7. Do please use the standard lube(oil) if need.
8. Do not connect any power when using.



Friendly Tips

If you need to moving the tripod position on shooting, do please take down the camera(especial for the telephoto lens),it may broke down your camera.